

DRAWN: B.MURPHY DT: 29-JUN-12

ENGR: S.HOGAN

DT: 29-JUN-12 | SCALE: 2:1

FINISH:

Use heat shrink to cover crimp.

Use the nut and washer to secure the connector to a case.

7.

SHEET 1 OF 1 LDCFDLT A

D

CONREVSMA005

DO NOT SCALE DRAWING